

PRODUCT INFORMATION

PRO CARE RADIATOR LEAK STOP

Description

Radiator Leak Stop Immediately and permanently seals hair-line cracks and leaking areas in the coolant circuit. Prevents seal transpiration and coolant loss. Compatible with all standard anti-freezes and coolants.

Benefits

- Secures the coolant circuit against leaks
- Seals without bonding
- Prevents seal transpiration and coolant loss
- Fully compatible with anti-freezes and coolants
- Neutral against rubber and plastics, light alloys and non-ferrous metals
- Permanent sealing of hairline cracks and leaking areas Heating taps and water pumps are functionally secured

Application

- For transpiration-soaked head gaskets
- For non-tight hose connections
- For hairline cracks in the radiator, cylinder head or engine block
- In case of coolant loss

Add to a warm engine. Open the heater valves. Let the engine run for at least 20 minutes until the thermostat opens. Then, switch off the engine, check the coolant level, absence of air and leak tightness again. Sufficient for up to 5 litres of coolant.



VOLUME

250 ml 500 ml 20 ltr 208 ltr

PACKAGING

24 Pcs. 12 Pcs. 1Pc 1Pc
1 Box 1 Box Drum Drum